



**AIR VALVE EXHAUST  
VA061**


**VA061-100**




$L_{p10A}$ : Sound pressure incl. 4dB room attenuation




**VA061-125**




$L_{p10A}$ : Sound pressure incl. 4dB room attenuation




**VA061-160**




$L_{p10A}$ : Sound pressure incl. 4dB room attenuation



**VA061-200**




$L_{p10A}$ : Sound pressure incl. 4dB room attenuation




**AIR VALVE SUPPLY  
VT061**


**VT061-100**




**VT061-125**




**VT061-160**



$L_{p10A}$ : Sound pressure incl. 4dB room attenuation



**VT061-200**



$L_{p10A}$ : Sound pressure incl. 4dB room attenuation

